



## Heating Instructions

1. Take flat bread out of freezer and allow to defrost for up to 1.5 hours
2. Fill Bain Marie up to level with cold/hot water
3. Turn dial to high and wait for water to come up to heat
4. Once water is up to temperature, place frozen skewers in Bain Marie
5. Place Kofte and Mixed Kebab in one insert and the Chicken and Chicken Tikka in the other
6. As skewers are pre-cooked heat up with a lid on for about 30-40 mins depending on how many skewers you have in the inserts
7. Make sure the skewers are above 68 degrees by probing before serving
8. To serve, place bread in Bain Marie (optional) for 20 seconds to slightly warm it
9. Follow wrapping instructions to complete.

N.B Keep checking the water levels in the Bain Marie making sure that the level stays constant throughout the cooking process.